



Chair for Network Architectures and Services – Prof. Carle
Department for Computer Science
TU München

Master Course Computer Networks IN2097

**Prof. Dr.-Ing. Georg Carle
Christian Grothoff, Ph.D.**

**Chair for Network Architectures and Services
Institut für Informatik
Technische Universität München
<http://www.net.in.tum.de>**



Technische Universität München



Chapter 6: Node Architectures

Our goals:

- ❑ understand main components of node architectures
- ❑ understand differences of packet-oriented and circuit-oriented protocol architectures
- ❑ understand principles for switching and virtualisation
- ❑ understand instantiations and implementations



6: Node Architectures

- ❑ 6.1 Virtual Circuit and Datagram Networks
- ❑ 6.2 What's inside a Router
- ❑ 6.3 Link virtualization: ATM, MPLS



Classification of Switches

- Packet vs. circuit switches
 - packets have headers and samples don't
- Connectionless vs. connection oriented
 - connection oriented switches need a call setup
 - setup is handled in *control plane* by *switch controller*
 - connectionless switches deal with *self-contained* datagrams

	<i>Connectionless (router)</i>	<i>Connection-oriented (switching system)</i>
Packet switch	Internet router	ATM switching system
Circuit switch		Telephone switching system



Requirements

- ❑ Capacity of a switch is the maximum rate at which it can move information, assuming all data paths are simultaneously active
- ❑ Primary goal: **maximize capacity**
 - subject to cost and reliability constraints
- ❑ Circuit switch must reject call if can't find a path for samples from input to output
 - goal: **minimize call blocking**
- ❑ Packet switch must reject a packet if it can't find a buffer to store it awaiting access to output trunk
 - goal: **minimize packet loss**
- ❑ **Don't reorder** packets



Connection setup

- In addition to routing and forwarding, 3rd important function in some network architectures:
 - ATM, frame relay, X.25
- before datagrams flow, two end hosts and intervening switches/routers establish virtual connection
 - switches/routers get involved
- network vs transport layer connection service:
 - **network**: between two hosts (may also involve intervening switches/routers in case of VCs)
 - **transport**: between two processes



Network service model

Q: What *service model* for “channel” transporting datagrams from sender to receiver?

Example services for individual datagrams:

- ❑ guaranteed delivery
- ❑ guaranteed delivery with less than 40 msec delay

Example services for a flow of datagrams:

- ❑ in-order datagram delivery
- ❑ guaranteed minimum bandwidth to flow
- ❑ restrictions on changes in inter-packet spacing



Network layer service models

Network Architecture	Service Model	Guarantees ?				Congestion feedback
		Bandwidth	Loss	Order	Timing	
Internet	best effort	none	no	no	no	no (inferred via loss)
ATM	CBR	constant rate	yes	yes	yes	no congestion
ATM	VBR	guaranteed rate	yes	yes	yes	no congestion
ATM	ABR	guaranteed minimum	no	yes	no	yes
ATM	UBR	none	no	yes	no	no



Network layer connection and connection-less service

- ❑ datagram network provides network-layer connectionless service
- ❑ VC network provides network-layer connection service
- ❑ analogous to the transport-layer services, but:
 - **service:** host-to-host
 - **no choice:** network provides one or the other
 - **implementation:** in network core



Virtual circuits

“source-to-destination path behaves much like telephone circuit”

- performance-wise
 - network actions along source-to-destination path
-
- ❑ call setup, teardown for each call *before* data can flow
 - ❑ each packet carries VC identifier (not destination host address)
 - ❑ *every* router on source-to-destination path maintains “state” for each passing connection
 - ❑ link, router resources (bandwidth, buffers) may be *allocated* to VC (dedicated resources = predictable service)




VC implementation

a VC consists of:

1. path from source to destination
 2. VC numbers, one number for each link along path
 3. entries in forwarding tables in routers along path
- packet belonging to VC carries VC number (rather than destination address)
 - VC number can be changed on each link.
 - New VC number comes from forwarding table



Forwarding table



Forwarding table in northwest router:


Incoming interface	Incoming VC #	Outgoing interface	Outgoing VC #
1	12	3	22
2	63	1	18
3	7	2	17
1	97	3	87
...

Routers maintain connection state information!



Virtual circuits: signaling protocols


- used to setup, maintain teardown VC
- used in ATM, frame-relay, X.25
- not used in today's Internet





Datagram networks

- no call setup at network layer
- routers: no state about end-to-end connections
 - no network-level concept of “connection”
- packets forwarded using destination host address
 - packets between same source-dest pair may take different paths





Datagram or VC network: why?

Internet (datagram)

- data exchange among computers
 - “elastic” service, no strict timing req.
- “smart” end systems (computers)
 - can adapt, perform control, error recovery
 - simple inside network, complexity at “edge”
- many link types
 - different characteristics
 - uniform service difficult

ATM (VC)

- evolved from telephony
- human conversation:
 - strict timing, reliability requirements
 - need for guaranteed service
- “dumb” end systems
 - telephones
 - complexity inside network



6: Node Architectures


- 6.1 Virtual Circuit and Datagram Networks
- 6.2 What's inside a Router
- 6.3 Link virtualization: ATM, MPLS



Router Architecture Overview


Two key router functions:

- run routing algorithms/protocol (RIP, OSPF, BGP)
- *forwarding* datagrams from incoming to outgoing link





Input Port Functions






Decentralized switching:

- ❑ given datagram destination, lookup output port using forwarding table in input port memory
- ❑ goal: complete input port processing at 'line speed'
- ❑ queuing: if datagrams arrive faster than forwarding rate into switch fabric



Three types of switching fabrics






Switching Via Memory

First generation routers:


- traditional computers with switching under direct control of CPU
- packet copied to system's memory
- speed limited by memory bandwidth (2 bus crossings per datagram)





Switching Via a Bus

- ❑ datagram from input port memory to output port memory via a shared bus
- ❑ **bus contention:** switching speed limited by bus bandwidth
- ❑ 32 Gbps bus, Cisco 5600: sufficient speed for access and enterprise routers






Switching Via An Interconnection Network

- ❑ overcome bus bandwidth limitations
- ❑ Banyan networks, other interconnection nets initially developed to connect processors in multiprocessor
- ❑ advanced design: fragmenting datagram into fixed length cells, switch cells through the fabric.
- ❑ Cisco 12000: switches 60 Gbps through the interconnection network




Output Ports



- ❑ *Buffering* required when datagrams arrive from fabric faster than the transmission rate
- ❑ *Scheduling discipline* chooses among queued datagrams for transmission



Output port queueing




- buffering when arrival rate via switch exceeds output line speed
- *queueing (delay) and loss due to output port buffer overflow!*




Input Port Queuing

- ❑ Fabric slower than input ports combined -> queueing may occur at input queues
- ❑ **Head-of-the-Line (HOL) blocking:** queued datagram at front of queue prevents others in queue from moving forward
- ❑ *queueing delay and loss due to input buffer overflow!*



output port contention
at time t - only one red
packet can be transferred



green packet
experiences HOL blocking



6: Node Architectures

- 6.1 Virtual Circuit and Datagram Networks
- 6.2 What's inside a Router
- 6.3 Link virtualization: ATM, MPLS



Virtualization of networks

- Virtualization of resources: powerful abstraction in systems engineering:
 - computing examples: virtual memory, virtual devices
 - Virtual machines: e.g., java
 - IBM VM operation system from 1960's/70's
- layering of abstractions: don't sweat the details of the lower layer, only deal with lower layers abstractly




The Internet: virtualizing networks

□ 1974: multiple unconnected nets


- ARPAnet
- data-over-cable networks
- packet satellite network (Aloha protocol)
- packet radio network

... differing in:

- addressing conventions
- packet formats
- error recovery
- routing



ARPAnet



satellite net

"A Protocol for Packet Network Intercommunication",
V. Cerf, R. Kahn, IEEE Transactions on Communications,
May, 1974, pp. 637-648.




The Internet: virtualizing networks

Internetwork layer (IP):

- ❑ addressing: internetwork appears as single, uniform entity, despite underlying local network heterogeneity
- ❑ network of networks

Gateway:

- ❑ “embed internetwork packets in local packet format or extract them”
- ❑ route (at internetwork level) to next gateway





Cerf & Kahn's Internetwork Architecture

- ❑ What is virtualized?
- ❑ two layers of addressing: internetwork and local network
- ❑ new layer (IP) makes everything homogeneous at internetwork layer
- ❑ underlying local network technology
 - cable
 - satellite
 - 56K telephone modem
 - today: ATM, MPLS
- ❑ ... “invisible” at internetwork layer. Looks like a link layer technology to IP!



ATM and MPLS

- ATM, MPLS separate networks in their own right
 - different service models, addressing, routing from Internet
- viewed by Internet as logical link connecting IP routers
 - just like dialup link is really part of separate network (telephone network)
- ATM, MPLS: of technical interest in their own right




Asynchronous Transfer Mode: ATM

- **1990's/00 standard for high-speed** (155Mbps to 622 Mbps and higher) *Broadband Integrated Service Digital Network* architecture

- **Goal: *integrated, end-end transport of carry voice, video, data***
 - meeting timing/QoS requirements of voice, video (versus Internet best-effort model)
 - “next generation” telephony: technical roots in telephone world
 - packet-switching (fixed length packets, called “cells”) using virtual circuits



ATM architecture



- **adaptation layer:** only at edge of ATM network
 - data segmentation/reassembly
 - roughly analagous to Internet transport layer
- **ATM layer:** “network” layer
 - cell switching, routing
- **physical layer**



ATM: network or link layer?


Vision: end-to-end transport:

“ATM from desktop to desktop”

- ATM is a network technology

Reality: used to connect IP backbone routers


- “IP over ATM”
- ATM as switched link layer, connecting IP routers





ATM Adaptation Layer (AAL)

- **ATM Adaptation Layer (AAL)**: “adapts” upper layers (IP or native ATM applications) to ATM layer below
- AAL present **only in end systems**, not in switches
- AAL layer segment (header/trailer fields, data) fragmented across multiple ATM cells
 - analogy: TCP segment in many IP packets






ATM Adaptation Layer (AAL) [more]

Different versions of AAL layers, depending on ATM service class:

- ❑ **AAL1:** for CBR (Constant Bit Rate) services, e.g. circuit emulation
- ❑ **AAL2:** for VBR (Variable Bit Rate) services, e.g., MPEG video
- ❑ **AAL5:** for data (eg, IP datagrams)





ATM Layer

Service: transport cells across ATM network

- analogous to IP network layer
- very different services than IP network layer

Network Architecture	Service Model	Guarantees ?				Congestion feedback
		Bandwidth	Loss	Order	Timing	
Internet	best effort	none	no	no	no	no (inferred via loss)
ATM	CBR	constant rate	yes	yes	yes	no congestion
ATM	VBR	guaranteed rate	yes	yes	yes	no congestion
ATM	ABR	guaranteed minimum	no	yes	no	yes
ATM	UBR	none	no	yes	no	no



ATM Layer: Virtual Circuits

- **VC transport:** cells carried on VC from source to dest
 - call setup, teardown for each call *before* data can flow
 - each packet carries VC identifier (not destination ID)
 - *every* switch on source-dest path maintain “state” for each passing connection
 - link, switch resources (bandwidth, buffers) may be *allocated* to VC: to get circuit-like perf.
- **Permanent VCs (PVCs)**
 - long lasting connections
 - typically: “permanent” route between to IP routers
- **Switched VCs (SVC):**
 - dynamically set up on per-call basis




ATM VCs

- Advantages of ATM VC approach:
 - QoS performance guarantee for connection mapped to VC (bandwidth, delay, delay jitter)
- Drawbacks of ATM VC approach:
 - Inefficient support of datagram traffic
 - one PVC between each source/dest pair) does not scale (N^2 connections needed)
 - SVC introduces call setup latency, processing overhead for short lived connections



ATM Layer: ATM cell


- 5-byte ATM cell header
- 48-byte payload
 - Why?: small payload -> short cell-creation delay for digitized voice
 - halfway between 32 and 64 (compromise!)





ATM cell header

- **VCI:** virtual channel ID
 - will *change* from link to link thru net
- **PT:** Payload type (e.g. RM cell versus data cell)
- **CLP:** Cell Loss Priority bit
 - CLP = 1 implies low priority cell, can be discarded if congestion
- **HEC:** Header Error Checksum
 - cyclic redundancy check





ATM Physical Layer (more)

Two pieces (sublayers) of physical layer:

- ❑ **Transmission Convergence Sublayer (TCS):** adapts ATM layer above to PMD sublayer below
- ❑ **Physical Medium Dependent:** depends on physical medium being used

TCS Functions:

- Header **checksum** generation: 8 bits CRC
- Cell **delineation**
- With “unstructured” PMD sublayer, transmission of **idle cells** when no data cells to send



ATM Physical Layer

Physical Medium Dependent (PMD) sublayer


- **SONET/SDH:** transmission frame structure (like a container carrying bits);
 - bit synchronization;
 - bandwidth partitions (TDM);
 - several speeds: OC3 = 155.52 Mbps; OC12 = 622.08 Mbps; OC48 = 2.45 Gbps, OC192 = 9.6 Gbps
- **T1/T3:** transmission frame structure (old telephone hierarchy): 1.5 Mbps/ 45 Mbps
- **unstructured:** just cells (busy/idle)



IP-Over-ATM


Classic IP only

- ❑ 3 “networks” (e.g., LAN segments)
- ❑ MAC (802.3) and IP addresses




IP over ATM

- ❑ replace “network” (e.g., LAN segment) with ATM network
- ❑ ATM addresses, IP addresses





IP-Over-ATM





Datagram Journey in IP-over-ATM Network


- **at Source Host:**
 - IP layer maps between IP, ATM dest address (using ARP)
 - passes datagram to AAL5
 - AAL5 encapsulates data, segments cells, passes to ATM layer
- **ATM network:** moves cell along VC to destination
- **at Destination Host:**
 - AAL5 reassembles cells into original datagram
 - if CRC OK, datagram is passed to IP



IP-Over-ATM

Issues:


- ❑ IP datagrams into ATM AAL5 PDUs
- ❑ from IP addresses to ATM addresses
 - just like IP addresses to 802.3 MAC addresses!





Multiprotocol label switching (MPLS)

- initial goal: speed up IP forwarding by using fixed length label (instead of IP address) to do forwarding
 - borrowing ideas from Virtual Circuit (VC) approach
 - but IP datagram still keeps IP address!





MPLS capable routers

- ❑ a.k.a. label-switched router
- ❑ forwards packets to outgoing interface based only on label value (don't inspect IP address)
 - MPLS forwarding table distinct from IP forwarding tables
- ❑ signaling protocol needed to set up forwarding
 - RSVP-TE
 - forwarding possible along paths that IP alone would not allow (e.g., source-specific routing) !!
 - use MPLS for traffic engineering
- ❑ must co-exist with IP-only routers



MPLS forwarding tables

